









VIDEO TUTORIAL

(i) Important!

This replacement procedure can be used for: $VW POLO (9N_{-}) 1.4 16V$

The steps may slightly vary depending on the car design.

WWW.AUTODOC.CO.UK



REPLACEMENT: SERPENTINE BELT – VW POLO 9N. LIST OF THE TOOLS YOU'LL NEED:



Combination spanner #16

Fender cover

WWW.AUTODOC.CO.UK 2–14



Replacement: serpentine belt – VW Polo 9N. AUTODOC experts recommend:

All work should be done with the engine stopped.

REPLACEMENT: SERPENTINE BELT – VW POLO 9N. USE THE FOLLOWING PROCEDURE:

1



Open the hood.

WWW.AUTODOC.CO.UK 3–14



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.


3



Lift the car using a jack or place it over an inspection pit.


WWW.AUTODOC.CO.UK 4–14





Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #16.


5



Remove the V-ribbed belt.

WWW.AUTODOC.CO.UK 5–14





Return the tensioner pulley to its initial position.

Replacement: serpentine belt – VW Polo 9N. Tip:

• Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

7



Install the V-ribbed belt.

WWW.AUTODOC.CO.UK 6–14



Replacement: serpentine belt – VW Polo 9N. AUTODOC recommends:

• Make sure that the V-ribbed belt fits all pulleys snugly.

8



Pull aside the V-ribbed belt tensioner pulley. Use a combination spanner #16.

9



Place the V-ribbed belt on the tensioner pulley.


WWW.AUTODOC.CO.UK 7–14





Return the tensioner pulley to its initial position.

11



Lower the car.

WWW.AUTODOC.CO.UK 8–14





Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

13

Shut off the engine.

14

Remove the fender protection cover.

15



Close the hood.

WWW.AUTODOC.CO.UK 9–14



DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES

NO




BECOME A MEMBER OF AUTODOC CLUB!

WWW.AUTODOC.CO.UK 10–14



AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE





WWW.AUTODOC.CO.UK







WWW.AUTODOC.CO.UK 12–14







WWW.AUTODOC.CO.UK 13–14





(i) Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.

WWW.AUTODOC.CO.UK 14–14